



**Cadillac Escalade (2001-2006)**  
**Chevrolet Avalanche (2002-2006), Chevrolet Pickup (2000-2006)**  
**Chevrolet Suburban (2000-2006), Chevrolet Tahoe (2000-2006)**  
**GMC Pickup (2000-2006), GMC Denali, Yukon, Yukon XL (2000-2006)**  
**( New body style only A/T only)**

**PART NUMBER: CV-71-99**

**PLEASE READ COMPLETE INSTRUCTIONS BEFORE INSTALLING THIS Pro.Fit VSM®.**

All instructions assume a drivers seat vantage point. Caution is advised when removing and reassembling wood or plastic parts of a dash. Applying unnecessary force or pressure may cause a piece to crack or break.

**Pro.Fit logo and part number will be right side up and readable when installed.**

**TOOLS REQUIRED:** 9/32" socket & driver.

**PARTS INCLUDED:** **Pro.Fit VSM®**, instructions.

**LOCATION:** To the right of the air vent that is to the right of the radio.

**STEP 1.**

Begin by removing the trim bezel that surrounds the instrument cluster, radio, and climate control. This bezel extends from the left of the steering wheel to the right of the radio. Slide ashtray out. With your hand palm side up, grasp the lower section of the bezel just above the ashtray. Pull toward you to release the first clip. Using the same action, continue working the bezel loose in a counter clockwise motion releasing a total of eleven (11) clips. **NOTE: For automatic transmissions with a column shift only. Apply the emergency brake. Insert the key and turn the ignition to the "on" position. Place the transmission into low gear.**

**STEP 2.**

If applicable, tilt the adjusting steering wheel to its lowest position. Grasp the trim bezel and carefully pull it away from the dash. Set the bezel aside. Place the transmission back into park and turn the ignition to the off position.

**STEP 3.**

Locate two (2) 9/32" hex-head screws to the right of the air vent that is to the right of radio. Remove the screws with the 9/32" socket and driver. Align the **Pro.Fit VSM®** over the two screw holes. Insert the bottom factory screw first and tighten. Then insert the top screw and tighten.


**STEP 4.**

Re-assemble the dash in reverse order. Install the phone holder onto the **Pro.Fit VSM®**.

This completes the installation of your **Pro.Fit VSM®**.



**Pro.Fit International, Inc.®** may not be held liable for any damage to a vehicle before, during or after the installation or removal of this **Pro.Fit VSM®**. **Pro.Fit** may not be held liable for any personal injury resulting from accident or improper installation. **Pro.Fit International, Inc.®** 1335 Eagandale Court, Eagan, MN 55121, Ph: 651-688-3588 or 800-388-0073 Fx: 651-688-9876



© **Pro.Fit International**, Eagan, MN 2005

